


S4A INDUSTRIAL CO.,LIMITED



INSTALLATION INSTRUCTIONS FOR THE WATERPROOF MANUAL CALL POINT







Installation

The integral back box has three 20mm diameter threaded holes. Two hole stoppers are provided for use as required. The cable entry holes of the back box must not be subjected to stress by the cable or conduit. The use of sealant such as Loctite product 5331 is recommended.

Wiring

Connection to the MCP is made via the 4 way terminal connector as shown overleaf Each terminal will accommodate a conductor of 2.5mm².

Earthing

An Earth Continuity Terminal is situated in the rear of the back box. This is designed to accommodate 2 conductors of up to 2.5mm². An earthing plate is provided tor continuity of metal conduits. This must be placed behind the back box prior to fixing the box to the wall.



Important Notes; -

Please do not over tighten fixing screws.

The use of lubricants, cleaning solvents or petroleum based products should be avoided.

The O-ring should be replaced when refitting or replacing the Waterproof Cover.

INSTALLATION INSTRUCTIONS FOR THE WATERPROOF MANUAL CALL POINT

WATERPROOF MCP


This Model provides double pole changeover contacts.

General

These Call Points are suitable for IP67 environments.

Wall Mounting of Back Box


Mount the back box to a suitably flat surface using the three fixing holes and the screws provided in the installation pack. The cable entry holes should be in the vertical plane. The back box can be mounted with either the single or the double entry holes at the top.



MCP Cover removal

To remove the cover, undo and remove the 4 Cover fixing screws. Place the edge of a large flat bladed screwdriver into the slot between the Cover and back box as shown in below and gently twist until the latches are


disengaged. Pull cover away from back box.





97.5mm 43mm 43mm


Fitting the MCP Cover to the back box

Plug the 4 way terminal connector onto the appropriate position as shown. Ensure that the O-ring is correctly seated in the channel on the rear of the cover. Place the cover squarely over the back box and carefully push the cover until the locating clips have engaged. Do not use excessive force. It is recommended that the 4 cover fixing screws are used to lock the cover into place.













64A INDUSTRIAL CO.LIMITED www.s4a-access.com E-mail:sales@s4a-access.com